


Pour brûleurs sans bornier / Per bruciatori senza morsettiera / Para quemadores sin regleta de conexiones
 For burners without a terminal strip / Brenner ohne Klemmleiste / Voor branders zonder klemmenkast

CASSETTE
26A




Effectuer le pont T1/T2
dans la prise 7 poles client.


Thermostat limiteur (contact relayé)
 Termostato limite (contatto scambiato)
 Termostato limitador (contacto retransmitido)
 Limit thermostat (switched contact)
 Begrenzer (übertragener Kontakt)
 Thermostaat-begrenzer (contact via relais)

Thermostat limiteur / Termostato limite
 Termostato limitador / Limit thermostat
 Begrenzer / Thermostaat-begrenzer

CASSETTE
26B




2 allures / AGP 2 stadi / AGP
 2 etapas / AGP 2 speeds / AGP
 2-stufig / AGP 2 trappen / AGP



Alimentation / Alimentazione
 Alimentación / Power supply
 Einspeisung / Voeding

Sonde / Sonda
 Sonda / Sensor
 Sonde / Sensor



2 allures / AGP
 2 stadi / AGP
 2 etapas / AGP
 2 speeds / AGP
 2-stufig / AGP
 2 trappen / AGP



Débrancher l'aquastat 2ème allure
 Scollegare il termostato 2° stadio
 Desconectar el aquastat 2a etapa
 Disconnect the stage 2 aquastat
 Kesselthermostat 2.Stufe abklemmen
 De ketelthermostaat van de
 2e trap afkoppelen

	Aend./Modification	Dat.	Vis.		Dat.	Vis.	Art. N°:	13014612.A	Type	Régulateur RC 6170	Blatt/Page
a	am10034	13.11.03		gez.	13.11.03	cod	Bez./Des.1	Schema électrique			1
b				dess.			Bez./Des.2	Brûleurs sans bornier	Schema	D993250	Tot. Bl/Pg
c				gepr.	13.11.03				Draw.		1
d				contr.							